



- 1) Please align the weathershields to the window. Please refer to the original ad. If unsure, please let us know and we can provide further information.
- 2) Mark out the points where the holes in the weathershields are and put clips in place. (Refer to image 1)
- 3) Stick on the weathershields. We recommend using a heat gun/hairdryer to warm up the tape for better adhesion. Also use the adhesion promoter if provided.
- 4) Place the lock piece in the hole and through the clip. (Refer to image 2 and 3)
- 5) Loosely place the bolt into the lock piece. DO NOT push it in (Refer to image 4)
- 6) Looking from the inside, like in image 5, place the donut onto the lock piece. The smooth face of the donut faces the inside of the vehicle.
- 7) Push the bolt all the way through. This will spread the locking piece and lock it into the donut.
- 9) Your weathershield is now installed and secure!

We hope that this helps.

Feel free to contact us if you require any more assistance with any specific parts of the installation process.